

Assembly Instruction

ITEM: 3613-04 END TABLE

PART LIST					HARDWARE LIST				
A	GLASS TOP/BOTTOM G1ASS	-	2 PCS	1	BOLT	()	5/16 "* 1-1/2 "	16 PCS	
В	TOP FRAME		1 PC	2	LOCK WASHER		5/16"	16 PCS	
С	BOTTOM FRAME		1 PC	3	FLAT WASHER		5/16"*16mm	16 PCS	
D	LEG		4 PCS	4	PAD		Ø 8*2mm	16 PCS	
				5	ALLEN KEY		5mm	1 PC	


NOTICE: DO NOT FULLY TIGHTEN THE BOLTS UNTIL IT IS


COMPLETELY ASSEMBLED.



STEP 2

STEP 3







For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.