

ASSEMBLY INSTRUCTION ITEM NO.: 8477BEG-VC

Armless Reversible Chaise with Hidden Storage

Legs and hardware are stored in chaise storage, please take out for assembly.


Note: Do not use power tools for assembly.Power tools increase the risk of over tightening which lead to Splitting or cracking the wood.


COMPONENT LIST


No	Drawing	Qty	Description
В		1	BACK CUSHION (PACKED IN 8477-VT)
С		1	BACK REST
E		1	CHAISE SEAT
Н		2	Plastic LEGS 4"x4"x2"
I	ľ	2	Plastic LEGS Ø2"x2"

HARDWARE LIST (PACKED IN 8477BEG-VC)

No	Drawing	Qty	Description
J	Description	4	SCREW Ø1/5*2"
L		2	BOLT 5/16"*2 3/8"
0		1	ALLEN KEY







Care Instruction for Fabric Furniture:

In order to maintain the original appearance of your fabric Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Fabric.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.