








Assembly Instructions


ITEM NO.: 9015BE/BU/GY-1LTM
POWER LIFT CHAIR WITH
MASSAGE, HEAT & USB PORT

Note: Do not use power tools for assembly. Power tools increase the risk of over-tightening which leads to splitting or cracking the wood.


Component List

No	Drawing	Qty	Description
A		1	SEAT
B		1	BACKREST
C		1	LSF EAR
D		1	RSF EAR
E		1	ADAPTER


Step #1



Step #2






Step #3






Step #4

Massage Controller





LIFT



RECLINE

I. Operation & Hand Controller Guide

* Input: AC 100–240V, 50/60Hz; Output: DC 29V, 2A

* After powering on, the chair enters standby mode.

All functions are operated via the hand controller.

II. Button Functions:

1.  : Power button – press to turn the unit on / off.
2. **TIME** : Press to cycle through three timer settings (10 / 20 / 30 min).
3. **MODE** : Press to cycle through massage modes: M1 → M2 → M3.
4. **INT** : Vibration massage intensity: 3 levels – High / Medium / Low.
5. **HEAT** : Press once to turn heating ON; press again to turn it OFF.
6.  : Press and hold to raise the chair. Release to stop at any position.
7.  : Press and hold to lower the chair. Release to stop at any position.
8.  : One-touch button to raise the chair to the standing position.
9.  : One-touch button to recline the chair and open the footrest.
10. USB charging port
11. Intensity indicator – H / M / L
12. Timer indicator – 10 / 20 / 30 min
13. Mode indicator – M1 / M2 / M3

III. Product features

1. 8 vibration massage motors (located in backrest and seat)
2. Single-zone heating pad
3. 3 massage modes (M1 → M2 → M3)
4. 3 vibration intensity levels (High / Medium / Low)
5. Three timer settings (10 / 20 / 30 minutes; defaults to 10 minutes upon start)
6. Single linear actuator with smooth lift / recline control
7. USB charging port (5V / 2.0A)

Care Instructions for Chenille Fabric Furniture:

In order to maintain the original appearance of your Chenille Furniture, please follow the simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage Chenille.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.



For items used on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to prevent damage, scratches and discoloration.

Warning!

Do not allow the electrical cord to be pinched between moving parts or between the frame and the floor. Do not place the cord under carpet or in a location where it could become worn.