



ASSEMBLY INSTRUCTION


ITEM NO: 9069BEG-3 SOFA



Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

NO.	DRAWING	DESCRIPTION	QTY
A		Seat Frame	1 PC
B		Back Frame	1 PC
C		Left Back Cushion	1 PC
D		Right Back Cushion	1 PC
E		Wooden Leg (Ø45*H120mm)	1 PC


Location of KD parts




ASSEMBLY INSTRUCTION

ITEM NO: 9069BEG-3 SOFA

STEP 1: Attach Wooden Leg (E) to Seat Frame (A).




STEP 2: Attach Back Frame (B) to Seat Frame (A).




ASSEMBLY INSTRUCTION

ITEM NO: 9069BEG-3 SOFA

STEP 3: Attach Back Cushion (C), (D) to Seat Frame (A).



STEP 4: Completed.



Care Instruction for Fabric Furniture:

In order to maintain the original appearance of your Fabric Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Fabric.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.