





STEP 1: Location of KD parts
Take out legs from the zippered pocket.




ASSEMBLING INSTRUCTIONS

ITEM NO: 9169DGY-1/ / 9169NBR-1 CHAIR

STEP 2: Use Allen Bolt (F), Lock Washer (G), Flat Washer (H) and Allen Key (I) to fix Wooden Leg (E) on Seat Frame (A).




STEP 3: Attach Back (B) to Seat Frame (A).




ASSEMBLING INSTRUCTIONS

ITEM NO: 9169DGY-1/ / 9169NBR-1 CHAIR

STEP 4: Attach Seat Cushion (C) and Back Cushion (D) to Seat Frame (A).



STEP 5: Completed.



CARE INSTRUCTION FOR LEATHER FURNITURE

In order to maintain the original appearance of your furniture, please follow below care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. sunlight and/ or exposure to heating and air conditioning outlets will fade/damage leather. Do not place your upholstered furniture too close to windows, radiators, vents and be sure to use window treatments to block the sun's rays

°Wipe with a soft brush to remove dust

*Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.

*For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and Supports to avoid/prevent from damages/scratches and discoloration.